

USER MANUAL









WARNING

THE PRODUCT IS TO BE ASSEMBLED BY AN ADULT.



WARNING

Potential hazard description, e.g. In unassembled state contain potentially hazardous sharp points, so please keep out of child's reach




























Steps for Unfolding:

- 1. Take the Aluminum Folding Goal post out of the package and hold it vertically from the floor as shown in Fig 1.
- 2. Spread both the arms of the Goal Post away from each other as shown in Fig 2.
- 3. Pull the Legs of the Goal Post up and away as shown in Fig 3.
- 4. Join both the legs of the Goal Post with each other using the connector as shown in Fig 4.
- 5. Close the flap over the connector using the Velcros and push the Goal Post down to keep it in upright position as shown in Fig 5.
- 6. Bingo! Your Goal Post is ready to use.

Steps for Folding:

7. Open the flap over the connector and pull the legs of the Goal post away from each other to disconnect the connector as shown in Fig 7.

Note: In case you face difficulties in opening the connectors, you can do some oiling / greasing for smooth operation. Still if you face difficulties in opening, you can loosen the Velcros of the Mesh Net to easily open the connectors.

- 8. Push the Legs down so they are laid flat against the surface as shown in Fig 8.
- 9. Fold one of the arms towards the other arm as shown in Fig 9.
- 10. Your Goal Post is folded and can be transported easily as shown in Fig 10.



WARNING

- This Aluminum Folding Goal Post is made from Powder Coated Aluminum. Do NOT leave the Aluminum Folding Goal Post outside after use because moisture will lower the life of the Aluminum Folding Goal Post. Avoid bringing the Aluminum Folding Goal Post in contact with water, moisture or dampness of any kind.
- 2. Store in a cool and dry place.
- 3. Do NOT leave the Aluminum Folding Goal Post unnecessarily exposed to UV rays and direct sunlight.
- 4. Children under 10 years of age must only assemble under the supervision of an adult.
- 5. Please keep small children away from the net to reduce risk of entanglement. Do not let children climb on the Aluminum Folding Goal Post. Exercise caution while using the Aluminum Folding Goal Post when small children are around! The manufacturer or the seller are not liable for any complications arising from the misuse of this product.

CLEANING

- 1. Do NOT wash the Aluminum Folding Goal Post. Only wipe clean with a dry cloth.
- 2. Avoid contact with any corrosive liquids or substances such as water, salt water, fuel, kerosene, etc. at all times. Oils and such chemicals can damage the net and reduce their life significantly.

TRANSPORT AND STORAGE

- The Aluminum Folding Goal Post is best moved in the folded position as delivered. Should you want to move the Aluminum Folding Goal Post in assembled/upright position, please move with two people to spread weight and reduce risk of injury.
- 2. Store in a cool and dry place, away from sunlight and dampness. Damp environment may lead to development of mould on the net.