



PRO Soccer Rebounder 88cms x 88cms

USER MANUAL



WARNING

**THE PRODUCT IS TO BE
ASSEMBLED BY AN ADULT.**



WARNING

Potential hazard description, e.g. In unassembled state contain potentially hazardous sharp points, so please keep out of child's reach






PRO Soccer Rebounder 88cms x 88cms

CONTENT

1



1 PC



ASSEMBLY

1. Take the rebounder out of the package.
2. Place the rebounder on a level surface (fig.1).
3. Lift the front frame with net upwards (fig.2).
4. Slide the pipe that is connected to the top of the front frame into the pipe that is connected to the base of the frame (fig.3).
5. Pull up the pin and slide the pipe to the desired angle (fig.4).
6. Place the pin back into one of the holes of the steel pipe to secure the rebounder (fig.5).
7. Your rebounder is now ready to use (fig.6).





PRO Soccer Rebounder 88cms x 88cms



CHANGING ANGLE

1. Pull up the pin from at the back of the rebounder (fig.7).
2. Slide the steel pipe up / down to reach your desired angle while holding the pin in pulled-out position (fig.8).
3. When the desired angle is reached, place the pin back into one of the holes of the steel pipe to secure the rebounder (fig.9).
4. The angle of your rebounder has now been changed.



STORAGE & TRANSPORT

1. Store the rebounder after each use.
2. Pull the pin on the black pipe (fig.10) and slide the steel pipe out of the black pipe (fig. 11) and fold both pipes to the net.
3. Lower the front frame with the net towards the ground (fig.12).
4. You can now move and/or store your rebounder. Use the bottom frame as a handle (fi g.13).





PRO Soccer Rebounder

88cms x 88cms

WARNING

1. This rebounder is made from Steel. Do NOT leave the rebounder outside after use because moisture will lower the life of the rebounder. Avoid bringing the rebounder in contact with water, moisture or dampness of any kind.
2. Store in a cool and dry place.
3. Do NOT leave the rebounder unnecessarily exposed to UV rays and direct sunlight.
4. Children under 10 years of age must only assemble under the supervision of an adult.
5. Please keep small children away from the net to reduce risk of entanglement. Do not let children climb on the rebounder. Exercise caution while using the rebounder when small children are around! The manufacturer or the seller are not liable for any complications arising from the misuse of this product.

CLEANING

1. Do NOT wash the rebounder. Only wipe clean with a dry cloth.
2. Avoid contact with any corrosive liquids or substances such as water, salt water, fuel, kerosene, etc. at all times. Oils and such chemicals can damage the net and reduce their life significantly.

TRANSPORT AND STORAGE

1. The rebounder is best moved in the folded position as delivered. Should you want to move the rebounder in assembled/upright position, please move with two people to spread weight and reduce risk of injury.
2. Store in a cool and dry place, away from sunlight and dampness. Damp environment may lead to development of mould on the net.

